DuPont Industrial Nonstick Coatings

3-COAT SPRAY-ON SYSTEM FOR SUPERIOR RELEASE

Product Information

DuPont Industrial Nonstick Coatings are aqueous dispersions that are uniquely blended multi-coat systems of DuPont™ Teflon® PTFE (polytetrafluoroethylene), Teflon® FEP (fluorinated ethylene propylene copolymer), and Teflon® PFA (perfluoroalkoxy) to optimize performance. The exceptional properties provide superior abrasion resistance and extend service life.

Property Data

	Primer 857G-030	Midcoat		Topcoat
Product Code		857G-130	857G-135	857G-240
Properties ¹		,		
Color	Black	Pewter	Black	Clear
System Color	_	Pewter	Sparkling Black	_
Coverage, ² m ² /kg (m ² /L) (ft ² /gal)	4.10 (4.72) (189)	7.4 (9.96) (406)	7.4 (9.82) (400)	7.11 (9.31) (379)
Coverage at DFT, ³ m ² /kg	12.8 (at 8µ)	10.32 (at 18μ)	10.25 (at 18μ)	19.74 (1054) (at 9µ)
Viscosity, ⁴ centipoises	250 – 375	250 - 450	600 - 900	300 - 450
Volume Solids, %	11.3 – 12.3	24.3 - 25.5	24 - 25.2	22.7 - 23.9
Weight Solids, %	22.5 – 24.5	41.5 - 43.5	40.9 - 42.9	39.2 - 41.2
Density, kg/l (lbs/gal)	1.15 (9.59)	1.34 (11.18)	1.33 (11.1)	1.31 (10.93)
Maximum In-Use Temperature, °C (°F)	260 (500)	260 (500)	260 (500)	260 (500)
Flash Point, SETA closed cup, °C (°F)	None	None	None	None

¹Physical constants are averages only and are not to be used as product specifications. They may vary up to 5% of the values shown



²Theoretical coverage at dry film thickness (DFT) of 1.0 mils (25µ) based on 100% application efficiency. It does not take normal production losses into account

³Theoretical coverage at given dry film thickness (DFT) and based on 100% application efficiency. It does not take normal production losses into account

⁴Brookfield RVT (Measured with spindle 2 at 20 RPM/25 °C)

Application Method

Substrate	required	Rolled and cast aluminum, Stainless steel		
Surface Preparation	recommended	Rolled: Defined profile curve has to be met by alkaline / alkaline-acid cleaning or by light gritblasting. / Cast: light gritblast / Stainless Steel: Gritblast Ra value: 120 µinch or 2.6 microns		
Filtering	required	100 mesh (appr.150μ) stainless steel or nylon		
Application	recommended	Spray on. Air pressure of 3-5 kg/cm ² and fluid delivery pressures of 0.8-1.2 kg/cm ² . HVLP gun air has to be increased. Primer sprayed preferably with conventional spray gun. Primer has to be stirred in the pressure pot at 30 rpm during application		
Product DFT*	recommended	PRIMER: 7 - 9μm MIDCOAT: 16 - 20μm TOPCOAT: 8 - 10μm		
Total DFT*	required	TOTAL: min. 33µm		
Ratio	recommended	PRIMER: 35 % MIDCOAT: 44 % TOPCOAT: 21 %		
Drying	recommended	Primer: Force dry (Ref. 5-8 min. at 120-150 °C (248-302 °F)). Temperature of primer between 35-45 °C (95-113 °F) before application of mid- and topcoat. Application of the midcoat and topcoat wet on wet.		
Curing	required	Total system: minimum 5 min. at 428 °C (802 °F) or 3 min. at 435 °C (815 °F) (metal temperature). Peak temperature should not exceed 440 °C (824 °F).		
Clean up	recommended	Water		
Thinner/Additive	required	Water		

^{*} Measured with Dual probe ED10 used in combination with the Dualscope MP20 and MP40 E-S

All recommendations are based upon best knowledge

Handling and Storage

- Primer & Midcoat: Gently mix (15 min at 30RPM) before use
- Topcoat: Stir with spatula or gently mix (15 min at 30RPM) before use
- Storage life is 12 months at room temperature (18 °C-27 °C)
- · Water-based product, protect from freezing.
- For medical application and development, consult DuPont.

For detailed information on health and safety, refer to the Material Safety Data Sheet and the latest edition of "The Guide to the Safe Handling of Fluoropolymer Resins," published by The Society of the Plastics Industry, Inc. (www.fluoropolymers.org) or by PlasticsEurope (www.plasticseurope.org).

Food Contact

This coating system is designed to be used in direct contact with food. Applied according to the application method and instructions on this fact sheet, the fully cured coating will comply with US FDA food contact regulations in 21CFR and can be sold and/or used for food contact applications for nonstick coatings in Europe following the national legislations of each European country, having specific regulations for this category of coatings (nonstick, high temperature resistant). Any changes or variations of individual coating thickness from what is indicated in this fact sheet should be assessed for food contact applications prior to its use. For details and information please contact your DuPont representative.

In Europe, in the case of incomplete compliance in one country, the product can, on the basis of its full compliance in at least one Member State of the European Union, be used for direct food contact in all Member States according to the Article 28-30 (ex Article 30-36) of the Treaty of Rome as amended.

Compositional statements, referring to relevant national legislation, are available on request.

Disposal and Other Considerations

Please follow these disposal guidelines as outlined in "The Guide to the Safe Handling of Fluoropolymer Resins," (available at www.fluoropolymers.org for download):

- All treatment, storage, transportation, and disposal of this product and/or container must be in accordance with applicable national and local regulations.
- Do not discharge aqueous dispersions to lakes, streams or waterways.
- Separate solids from liquid by precipitation and decanting or filtering. Dispose of dry solids in a landfill that is permitted, licensed or registered to manage industrial solid waste.
 Discharge liquid filtrate to a wastewater treatment system.
- Incinerate only if incinerator operates at 800 °C or higher and is capable of scrubbing out hydrogen fluoride and other acidic combustion products.
- Industrial fluoropolymer waste containing additives such as solvents, primers or thinners must be regarded as special waste. Companies should contact their local waste disposal authorities for details of the relevant waste disposal regulations.
- Empty containers should preferably be cleaned and recycled.
 If this is not possible, the containers should be punctured or otherwise destroyed before disposal.

For more information on DuPont Industrial Nonstick Coatings: www.teflon.com/industrial

DuPont Wilmington, Delaware, USA

Phone: U.S. callers: 1-866-205-1664 Fax: (302) 351-7264

P.O. Box 80702 Wilmington, DE 19880-0702

Latin America DuPont do Brasil, S.A. Sao Paulo, Brazil

Phone: 55:11-4166-8344 Fax: 55-11-4166-8732 Asia Pacific DuPont China Holding Co., Ltd. Shenzhen, China Phone: 86-755-83307848 Fax: 86-755-83405489

Europe DuPont de Nemours Belgium, BVBA Mechelen, Belgium

Phone: 32-15-441-180 Fax: 32-2-403-53-96

Copyright© 2011 Du Pont or its affiliates. All rights reserved. The DuPont Oval Logo, DuPont™, The miracles of science™, and Teflon® are registered trademarks or trademarks of E.I. duPont de Nemours and Company or its affiliates. K-25180-1 05/13

Teflon® is a registered trademark of E.l.du Pont de Nemours, only available under license and subject to qualification.

NO PART OF THIS MATERIAL MAY BE REPRODUCED, STORED IN A RETRIEVAL SYSTEM OR TRANSMITTED IN ANY FORM OR BY ANY MEANS ELECTRONIC, MECHANICAL, PHOTOCOPYING, RECORDING OR OTHERWISE WITHOUT THE PRIOR WRITTEN PERMISSION OF DUPONT.

All technical advice, recommendations and services are rendered by Seller free of charge. They are based on technical data which the Seller believes to be reliable, and are intended for use by persons having skill and know-how, at their own discretion and risk. Seller assumes no responsibility for results obtained or damages incurred from their use by Buyer in whole or in part. Such recommendations and technical advice or services are not to be taken as a license to operate under or intended to suggest infringement of any existing patent. All coverage figures are based on 100% application efficiency. These calculations do not take into account normal losses due to production conditions.

CAUTION: Do not use DuPont materials in medical applications involving implantation in the human body or contact with internal body fluids or tissues unless the material has been provided from DuPont under a written contract that is consistent with DuPont policy regarding medical applications and expressly acknowledges the contemplated use. For further information, please contact your DuPont representative. You may also visit www.teflon.com/industrial to download a copy of the DuPont POLICY Regarding Medical Applications H-50103 and DuPont CAUTION Regarding Medical Applications H-50102.

